


STANDARD ARRIVAL CHART
INSTRUMENT (STAR) - ICAO

TRANSITION
LEVEL: 1

SALEKHARD, RUSSIA
SALEKHARD
RNAV Rwy 04



CRUG
START
120,800
118,600

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES IN FEET
ELEVATIONS IN FEET AND METRES
HEIGHTS IN METRES
DISTANCES IN KILOMETRES

Alt set: -QNH(QNH on req);
-hPa (mm on req).

1 TRANSITION LEVEL:
- FLO70 when QNH is 984 hPa (738mm mercury column) or above;
- FLO80 when QNH is 948 hPa (711mm mercury column) or above,
but less than 984 hPa (738mm mercury column);
- FLO90 when QNH is less than 948 hPa (711mm mercury column).