STANDARD ARRIVAL CHART INSTRUMENT (STAR) - ICAO

TRANSITION LEVEL : ❶

PEVEK, RUSSIA

PEVEK
RWY 35



RADAR **124.200**

❶ TRANSITION LEVEL:
- FL070 when QFE is 760mm mercury column or above;
- FL080 when QFE is 733mm mercury column or above, but less than 760mm mercury column;
- FL090 when QFE is less than 733mm mercury column.

WARNING
When continuous radar control by TAR is not provided, ACFT shall proceed to NDB PK at transition level and turn RIGHT to join the procedure.

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES, HEIGHTS AND ELEVATIONS IN METRES
DISTANCES IN KILOMETRES

Alt set: -QFE(QNH on req);
-mm(hPa on req).

CHANGE: New chart